

## MANUAL

### GripFactory UltraGrip Concrete

**ATTENTION:** The room must be well ventilated.

**ATTENTION:** Read the safety data sheet before starting.

#### TOOLS REQUIRED

- Personal protective equipment (protective gloves and panoramic glasses);
- Watering can, wax coat, brush, vacuum cleaner and / or floor cleaner;
- Pressure sprayer with GripFactory UltraGrip Concrete (non-slip liquid for concrete and stone);
- GripFactory UltraGrip Cleaner (cleaning agent).

#### APPLICATION

1. Clean the floor with UltraGrip Cleaner (see manual UltraGrip Cleaner);
2. Spray the UltraGrip Concrete evenly over the floor with a pressure sprayer;
3. Spread the UltraGrip Concrete over the floor with a wax coat without leaving any streaks;
4. Allow the UltraGrip Concrete to work in for around 15 minutes without the floor drying. If there are dry spots, spread the liquid with the wax coat or spray the liquid;
5. After 15 minutes, neutralize the floor with water and scrub the floor thoroughly;
6. Then dry the floor with a wet vacuum cleaner or floor squeegee.

#### TIPS

- Always first make a test surface out of sight so that the effect of the anti-slip treatment is known;
- Beware of dark floors because of the "whitening" effect;
- Make sure the floor heating is off and prevent drafts as much as possible;
- Never treat more than 100 m<sup>2</sup> per session to achieve the correct skid resistance everywhere.

#### GRIPFACTORY APPLICATION SERVICE

Need help? Then contact the GripFactory Service Desk (+31 348 203000). For an additional cost you can have GripFactory UltraGrip applied by a certified applicator.