

## MANUAL

### GripFactory UltraGrip Marble

**ATTENTION:** The room must be well ventilated.

**ATTENTION:** Read the safety data sheet before starting.

#### TOOLS REQUIRED

- Personal protective equipment (protective gloves and panoramic glasses);
- Watering can, brush, wax coat, vacuum cleaner and / or floor cleaner;
- Pressure sprayer with GripFactory UltraGrip Marble (anti-slip liquid for marble);
- GripFactory UltraGrip Cleaner (cleaning agent).

#### APPLICATION

1. Clean the floor with UltraGrip Cleaner (see manual UltraGrip Cleaner);
2. Depending on the surface, dilute the UltraGrip Marble 1:5 or 1:10;
3. Spray the UltraGrip Marble evenly over the floor with a pressure sprayer;
4. Spread the UltraGrip Marble over the floor with a wax coat without leaving streaks;
5. Allow the UltraGrip to work in for around 30-45 minutes without the floor drying. If there are dry spots, spread the liquid with the wax coat or spray the liquid;
6. Test after 30 minutes whether the floor's roughness is sufficient. For a higher skid resistance, let the liquid work in even longer;
7. If the floor is sufficiently rough, neutralize with water and scrub the floor thoroughly;
8. Dry the floor afterwards with the vacuum cleaner or floor extractor.

#### TIPS

- Always first make a test surface out of sight so that the effect of the anti-slip treatment is known;
- Beware of dark floors because of the "whitening" effect;
- Make sure the floor heating is off and prevent drafts as much as possible;
- Never treat more than 100 m<sup>2</sup> per session to achieve the correct skid resistance everywhere.

#### GRIPFACTORY APPLICATION SERVICE

Need help? Then contact the GripFactory Service Desk (+31 348 203000). For an additional cost you can have GripFactory UltraGrip applied by a certified applicator.