

MANUAL GRIPFACTORY TITANIUMGRIP

ATTENTION: The room must be well ventilated.

ATTENTION: Read the safety data sheet before starting.

ATTENTION: The pressure sprayer used for GripFactory TitaniumGrip can only be used for GripFactory TitaniumGrip, so mark it clearly.

TOOLS REQUIRED:

- Personal protective equipment:
 - Filter mask for protection against chemical products
 - Non-disposable chemical resistant gloves
 - Integral frame safety glasses
 - Chemical resistant clothing
 - Chemical resistant footwear and with antistatic properties)
- One pressure sprayer for GripFactory TitaniumGrip
- One pressure sprayer for water
- Bucket with mop
- Water vacuum cleaner and / or floor cleaner
- Dry cloths

CLEANING:

- First clean seriously contaminated floors with the mop and degrease with GripFactory TitaniumGrip Cleaner. After this, vacuum dry thoroughly with the water cleaner.

TESTING:

- GripFactory TitaniumGrip Pro is available in three versions (A, D and F). Therefore always test a tile out of sight before application:
 - GripFactory TitaniumGrip shake well before use because the titanium molecules otherwise sink to the bottom.
 - Start with GripFactory TitaniumGrip Pro-A, hold the stopwatch and continue to feel until you get a grip. If it does not give sufficient grip after 3.5 minutes, stop and neutralize the tile with water. Then switch to GripFactory TitaniumGrip Pro-D and repeat the process on a different tile. If there is no sufficient grip, switch to F. If sufficient grip occurs within 3.5 minutes, remember the exposure time (write down) and then neutralize the test tile with water. Then dry the tile.

TREATMENT:

You can now treat the entire tile floor with the chosen version (A, D or F) and have it working during the noted exposure time. Neutralize in time to achieve the same result as with the test tile.

After a while you get experience and you immediately know which one you need. However, for Granito and natural stone floors you must always perform the above test method.



GripFactory B.V.

Trasmolenlaan 12
3447 GZ Woerden
The Netherlands

☎ +31 (0)348 - 20 30 00

✉ info@gripfactory.nl

🌐 www.gripfactoryantislip.com


TIPS:

- Always first make a test surface out of sight so that the effect of the anti-slip treatment is known.
- Beware of dark floors because of the “whitening” effect.
- Light-colored (ceramic) tiles never actually cause problems and will be treated with GripFactory TitaniumGrip Pro-D in 95% of the cases..
- Remove pits etc. from stainless steel and replace after treatment. This to prevent possible corrosion.
- Never step on a wet, sprayed floor. This is not a problem after neutralization with water.
- Cover the sprayer head with a dry cloth and make sure it never drips on anything. Place your tools outside the bathroom on a dry cloth if they are not being used.
- Never allow a sprayed floor to dry. Make sure the floor heating is off and prevent drafts as much as possible.
- Never treat more than 100 m² per session to obtain the correct anti-slip resistance everywhere.
- If possible on larger areas (+ 10m²), try to neutralize where you have started spraying.




GripFactory B.V.

Trasmolenlaan 12
3447 GZ Woerden
The Netherlands

 +31 (0)348 - 20 30 00

 info@gripfactory.nl

 www.gripfactoryantislip.com

GRIPFACTORY APPLICATION SERVICE

Problems or issues? Please contact the GripFactory Servicedesk (+31 348-203000). For an additional cost you can have GripFactory TitaniumGrip applied by a certified applicator.